




## HOW TO INSTALL SCAN~LINK RFID SAFETY SYSTEM® INTO HARD HAT INTERIOR

**STEP 1:** Remove hard hat suspension and clean any dirt, grease and grime from the *interior* surface of the hard hat.

**STEP 2:** Apply all ten (10) SCAN~LINK Armour® Tags one at a time to the *interior* of the hard hat at the locations shown in the diagram below. Ensure that the tags **A, B, C** and **D** are placed **3" (8cm)** above the headband.

**HOW TO INSTALL SCAN~LINK RFID SAFETY SYSTEM® INTO HARD HAT INTERIOR**

<p><b>STEP 1</b></p> <p>Remove hard hat suspension and clean any dirt, grease and grime from the <b>interior</b> of the hard hat.</p> <p><b>STEP 2</b></p> <p>Apply all ten (10) SCAN~LINK Armour® Tags one at a time to the interior of the hard hat at the locations shown in the diagram below – ensuring that tags <b>A, B, C</b> and <b>D</b> are placed <b>3" (8 cm)</b> above the rim of the hard hat.</p> <p><b>STEP 3</b></p> <p>Confirm tags are secured as shown in STEP 2, and re-install hard hat suspension.</p> <p>Your hard hat is now:</p> <p style="background-color: #90EE90; padding: 2px;"><b>SCAN~LINK Armour® Ready!</b></p>	<p style="text-align: center;"><b>ALL TEN (10) TAGS GO INSIDE THE HARD HAT</b></p> <div style="text-align: center;">  </div> <p style="text-align: center; color: red;"><b>DO NOT OVERLAP TAGS</b></p>
---	--

ALL SCAN~LINK SAFETY PRODUCTS ARE DESIGNED AS TOOLS TO ASSIST OPERATORS ONLY AND DO NOT TAKE AWAY ANY RESPONSIBILITY OF THE OPERATOR WHEN BACKING UP. SCAN~LINK WILL NOT BE HELD LIABLE FOR ANY DAMAGE, INJURY OR LOSS ASSOCIATED WITH ITS SAFETY PRODUCTS. THE SCAN~LINK SYSTEM DOES NOT REPLACE ANY SAFETY PROCEDURE OR RESPONSIBILITY IN PLACE.

## TAGS GO INSIDE HARD HAT

**STEP 3:** Confirm the tags are secured as shown in STEP 2, and re-install the hard hat suspension. Your hard hat is now **SCAN~LINK Armour® Ready!**